

To ensure that you get the most out of your himolla furniture for as long as possible, we recommend returning all functional elements to their initial position after use. Otherwise creases could appear in the cover, materials could be compressed or the mechanisms could be damaged.

Functional description: Signa

Model type:	03	07-12	13-14	15-16	17-18	25-30	35-40
	Stool	End récamier <ul style="list-style-type: none"> <li>• 1-seater with leg rest</li> <li>• Seat depth adjustment, electric</li> </ul>	End element 1 1/2-seater	End element 1 1/2-seater <ul style="list-style-type: none"> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, manual</li> </ul>	End element 1 1/2-seater <ul style="list-style-type: none"> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, electric</li> </ul>	End récamier <ul style="list-style-type: none"> <li>• 1-seater with leg rest</li> <li>• Seat depth adjustment, manual</li> </ul>	End récamier <ul style="list-style-type: none"> <li>• 1-seater with leg rest</li> </ul>
Declaration number:	--	187	160	188	186	159	160

Model type:	49-50	51					
	Open end element with integrated corner	Sofa 2 1/2-seater <ul style="list-style-type: none"> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, electric</li> </ul>					
Declaration number:	160	186					

Model type:	52	55-56	57-58	61	62	65-66	67-68
	Sofa 3-seater <ul style="list-style-type: none"> <li>• Seat divided into 2</li> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, electric</li> </ul>	End element, 2 1/2-seater <ul style="list-style-type: none"> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, electric</li> </ul>	End element, 3-seater <ul style="list-style-type: none"> <li>• Seat divided into 2</li> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, electric</li> </ul>	Sofa 2 1/2-seater	Sofa 3-seater <ul style="list-style-type: none"> <li>• Seat divided into 2</li> </ul>	End element, 2 1/2-seater	End element, 3-seater <ul style="list-style-type: none"> <li>• Seat divided into 2</li> </ul>
Declaration number:	186	186	186	160	160	160	160
Model type:	69-70	71-72	81	82	85-86	87-88	Rechargeable battery
	Open end element with integrated corner <ul style="list-style-type: none"> <li>• Seat depth adjustment, manual on the short side</li> </ul>	Open end element with integrated corner <ul style="list-style-type: none"> <li>• Seat depth adjustment, manual</li> </ul>	Sofa 2 1/2-seater <ul style="list-style-type: none"> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, manual</li> </ul>	Sofa 3-seater <ul style="list-style-type: none"> <li>• Seat divided into 2</li> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, manual</li> </ul>	End element, 2 1/2-seater <ul style="list-style-type: none"> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, manual</li> </ul>	End element, 3-seater <ul style="list-style-type: none"> <li>• Seat divided into 2</li> <li>• Leg rest adjustment, electric</li> <li>• Seat depth adjustment, manual</li> </ul>	<ul style="list-style-type: none"> <li>• Exchangeable battery</li> <li>• Charging station</li> </ul>
Declaration number:	159	159	188	188	188	188	93